

## PARTS LIST

---

### Recommended spare parts

#### Power supply

| <u>Part Number</u> | <u>Description</u>                            | <u>Designator</u> | <u>Qty.</u> |
|--------------------|---|-------------------|-------------|
| 129633             | Green power lamp assembly                     |                   | 1           |
| 027634             | Filter housing                                |                   | 1           |
| 027664             | Filter element                                |                   | 1           |
| 129792             | Chopper assembly                              | CH1               | 1           |
| 127039             | 6 in. fan: 230 CFM, 115 VAC 50 – 60 HZ        |                   | 1           |
| 027079             | 10 in. fan: 450 – 550 CFM, 120 VAC 50 – 60 HZ |                   | 1           |
| 003149             | Relay: Pilot arc, 120 VAC                     | CR1               | 1           |
| 041837             | PCB: I/O                                      |                   | 1           |
| 003249             | Contactator                                   | CON1              | 1           |
| 109004             | Current sensor: Hall 100 A, 4 volt            |                   | 1           |
| 229238             | Start circuit assembly                        | PCB1              | 1           |
| 008551*            | Fuse: 7.5 A, 600 volt                         | F1, F2            | 2           |
| 228548             | Control PCB                                   | PCB3              | 1           |
| 041802             | Power distribution PCB                        | PCB2              | 1           |
| 229206             | Flow switch assembly                          | FLS               | 1           |
| 027185             | Heat exchanger fan: 4 in.                     |                   | 1           |
| 006075             | Check valve: 1/4 in. FPT                      |                   | 1           |
| 229229             | Solenoid valve assembly                       | CLT SOL           | 1           |
| 228170             | Kit: Pump, 70 gpm, 200 psi                    |                   | 1           |
| 228538             | Kit: Motor, 1/3 HP, 240 volt, 50 – 60 HZ      |                   | 1           |

\* 400, 415, 480, and 600 volt power supplies

#### Ignition console

| <u>Part Number</u> | <u>Description</u> | <u>Designator</u> | <u>Qty.</u> |
|--------------------|--------------------|-------------------|-------------|
| 041817             | HFHV Ignition PCB  |                   | 1           |
| 129854             | Transformer        | T1                | 1           |

#### Gas console

| <u>Part Number</u> | <u>Description</u>       | <u>Designator</u> | <u>Qty.</u> |
|--------------------|--------------------------|-------------------|-------------|
| 041805             | Power distribution PCB   | PCB1              | 1           |
| 041822             | Valve driver PCB         | PCB3              | 1           |
| 005263             | Pressure sensor          | PT1 – PT3         | 1           |
| 006109             | Solenoid valve           | SV1 – SV14        | 2           |
| 005262             | Illuminated power switch | SW1               | 1           |

#### Off-valve

| <u>Part Number</u> | <u>Description</u> | <u>Designator</u> | <u>Qty.</u> |
|--------------------|--------------------|-------------------|-------------|
| 006109             | Solenoid valve     | V16 – V19         | 1           |